


## LXV8 - Preset List



In MANUAL Mode: **None correction or compensation applied.**

In AUTO Mode: **- Correction Applied with N boxes selected by user**  
**- Automatic Compensation with the data readed by the inclinometer.**